

RP1000

QUICK START MANUAL

1



#327C, Sigma2, Gumi-dong, Bundang-gu, Seongnam-si, Gyeonggi-do, 463-741, Rep. of Korea

Tel. +82-31-607-7537 Fax. +82-31-608-7537 Email : Tech@gen2wave.com



Revision History

Changes to the original manual are listed below:

Version	Date	Description
Rev 1.0	10/08/9	Initial release
Rev 2.1	10/10/28	Buttons and Parts
Rev 2.2	10/11/02	Design Changing

BUTTONS AND PARTS



- 1: Phone Speaker
- 2: Scan Button
- 3: Volume Up/Down Button
- 4: Scan Button
- 5: Microphone
- 6: Reset Button
- 7: I/O Connector
- 8: Power Button
- 9: Charging/Battery Status LED
- 10: Touch Screen
- 11: Start Menu
- 12: Soft Key
- 13: Talk
- 14: Navigation
- 15: End
- 16: Enter/OK Key

INSERT THE BATTERY

- ★ **NOTE** The RP1000 ships with either a 1860mAh or 3600mAh battery.
The 1860mAh battery is shown below.

To insert the battery.

1. Insert the battery top first into the battery compartment.
2. Press the battery down into the battery compartment.
3. Lock the Battery Release Latch.



To remove the battery.

1. Unlock the Battery Release Latch.
2. Lift off the down side of battery.

Charging the RP1000 Battery

Connect the cradle to power. Insert the RP1000 into the RP1000 slot to begin charging.




5



Before using the RP1000 for the first time, charge the main battery until fully charged.

CHARGING THE SPARE BATTERY




1. Insert the battery top first into the spare battery charging compartment.
2. Press and hold the battery bottom.
3. Lock the spare battery release latch.

Insert the SIM Card

6

To insert the SIM card:

1. Slide up the SIM card holder door up to unlock.
2. Lift the SIM card holder door.




3. Insert the SIM card.
4. Close SIM card holder door and slide down up to lock into place
5. Insert the battery.

INSERT MICROSD CARD

To insert the microSD card:

1. Slide up the microSD card holder door up to Open.
2. Lift microSD card holder door.



3. Insert the microSD.
4. Close microSD card holder door and slide down to lock into place.
5. Insert the battery.

SYNCHRONIZE THE RP1000 WITH YOUR WINDOWS PC

ActiveSync is a free application available from the Microsoft web site at www.windowsmobile.com/getstarted. Followed instructions.